

2010-2015 Camaro Battery Terminal Cover Installation Instructions

1. Remove Factory Cover



2. Install Wire Loom over Factory Battery Cable. If your Cable has the Hood Cable Attached, then you will need to fit the loom to that point and cut it and use the remainder of the loom for the rest of the cable.



3. Remove the Cap from the Base.
4. Install the base onto the factory terminal holder starting towards the engine at an angle and push into place. Once in place give it a tug to make sure it is locked into the tabs.



5. Now Install the Cap

