

2020 GT500/S650 Magneride Mustang Billet Vertical Link

Instructions for Part Number: 555-4137

1. Raise the car. If you are using a jack and jack stands, be sure to properly chock the front tires.
2. Remove the rear wheels for easier access to the vertical link.
3. Place a jack underneath the knuckle, where the toe link is attached. This will aid in keeping the knuckle in place, when the vertical link is removed.
4. Remove the bolt, securing the link to the lower control arm.
5. Remove the bolt and nut, securing the link to the knuckle.
6. Using the supplied grease pack, liberally apply grease to the surfaces of the polyurethane bushings.
7. Install the link, with the larger diameter end facing up. Insert the tapered bushing spacer into the upper bushing sleeve. The tapered steel sleeve will fit into the knuckle.
8. Start both bolts by hand before tightening. You'll be replacing the lower factory bolt and washer with the new 12mm x110mm long bolt and washer. This will provide more clearance when running wheels that are less than 19" in diameter in the rear.
9. Torque the top bolt to 129 ft-lbs. Torque the lower bolt to 76 ft-lbs.

