



## Steeda S550 Front Lower Control Arms

Installation Instructions for Part: 555-4906, 555-4907, 555-4908, and 555-4914



### Tools Required

- 1/2" drive ratchet
- 21 mm socket
- 24 mm socket
- Hammer

### Removal Instructions

1. Support the car on a lift or jack stands.
2. Remove the front wheels.
3. Remove both of the front lower control arms, indicated in Figures 1 and 2.

**NOTE:** Be careful not to damage the threads.



**Figure 1:** Factory lateral link

### Installation Instructions

1. Install the Steeda front lower control arms.  
**NOTE:** The arms are side specific. Compare them to the factory arms removed in order to ensure proper install.
2. Reusing the factory nuts and bolts, torque both arms to the following specs:

Front Lower Control Arm to Subframe (Inboard): 185 ft/lbs

Front Lower Control Arm to Spindle (Outboard): 85 ft/lbs

**NOTE:** An alignment is suggested after installing this part.

**NOTE:** Depending on wheel/tire size and offset, rubbing of the tire on the inner fender liner can be present at full lock.



**Figure 2:** Factory tension link