

Chassis Jacking Rail Installation Instructions

Tools Required:

- Ramps or jack and jack stands
- Ratchet Handle or Impact Gun
- 13mm, 15mm socket

Installation:

1. Place vehicle on ramps or lift vehicle and secure on jack stands

2. Remove all eight (8) bolts from the frame rail as shown in **IMAGE 1 and 2**.

NOTE: If your vehicle comes with felt closeouts, they will need to be trimmed as shown in **IMAGE 3a and 3b** to fit flush with the chassis jacking rails. The steel nutserts in the floorpan should also be removed.

3. Install jacking rails using the same factory bolts as shown in the last image.

NOTE: Drivers side rail is longer than passenger side and the closely spaced holes go toward the front of the vehicle on both rails.

4. Tighten to 41 ft/lbs.



IMAGE 1




IMAGE 2



IMAGE 3a



IMAGE 3b

WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to vehicle/person during installation or use of this product.



Chassis Jacking Rail Installation Instructions



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to vehicle/person during installation or use of this product.