

JLT 3.0 Oil Separator, Driver Side (2011-14 Mustang GT with Roush / VMP, Whipple or FRPP Supercharger; 2015-17 Mustang GT with Roush / VMP Supercharger) #3020D Installation Instructions

Please review complete instructions prior to installing.

1	Remove the stock line from the valve cover to the intake tube by pulling back the grey tab.
2	Remove the DRIVER FRONT 10mm bolt holding the blower to the lower manifold.
3	Use the bolt to install the JLT bracket and Torque fastener to 30Nm (22ft lbs)
4	

To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles. Thanks for the business. If you have any questions, please e-mail <u>info@JLTtruecoldair.com</u> or call 757-335-1940. Our hours are Monday-Friday. 8:00am – 5:00pm Eastern Time.

JLT Performance Lifetime Satisfaction Guarantee. We want you to be a JLT Performance customer for life! Your new JLT Performance product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. www.jlttruecoldair.com/warranty

We guarantee workmanship, tunability and even a pathway to discounted upgrades for substantially improved items.

<u>**Return Policy**</u>: All returns will be subject to a 10%-25% restocking fee. Please visit <u>www.JLTtruecoldair.com</u> for complete return policy.

Disclaimer: JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by JLT Performance Inc. agree to hold harmless and indemnify JLT Performance Inc. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.